

Installation of Febdok Version 8.0 Client

This is a guide for installing the Febdok version 8.0 client. The installation was performed on Windows 10. If you are using a different version of Windows, the screens may vary slightly, but the overall process remains the same.

System Requirements for Febdok Version 8.0 Client:

- Access Database Engine 2016 (32-bit or 64-bit)
- .NET Framework 4.8.2

The client installation can be found in the KlientSetup folder within the Febdok directory on the server.

The client must be run from the same location as the text file **FebDokInstallDir.txt**.

The installation inherits the installation directory from this text file.



Name	Date modified	Type	Size
 Febdok_Klient_x64.msi	22.05.2025 12:17	Windows Installer ...	8 276 KB
 FebDokInstallDir.txt	02.06.2025 08:52	Text Document	1 KB

Figure 1 Run Febdok_Klient_64.msi to install the client.




Figure 2 Click "next"




Figure 3 Click "Install"




Figure 4 Click 'Finish' to complete the installation.



Febdok komplett

Version	8.0 (64bit)
Versjonsdato	22.05.2025
Lisensstype	Klient
Lisensnr.	4004
Lisensstaker	NHO Elektro
Brukernavn	

Febdok: Bruker pålogging

Brukernavn

Passord





Figure 5 Log in to the Febdok client.

First-Time User Login in Febdok

The first time you log in with a user account in Febdok version 8.0, you must accept an End User Agreement. This does not apply to the admin user.

The agreement only needs to be accepted once per user.

If you do not accept the agreement, you will not be able to use the program.



Febdok Complete

Version	8.0 (64bit)
Version date	22/05/2025
License type	Client
License No.	4004
Licensee	NHO Elektro
Username	

Febdok: User login

Username

Password




Figure 6 Log in with a user for the first time.

Du må akseptere sluttbrukeravtalen for å bruke Febdok:

Sluttbrukeravtale for Febdok

- Definisjoner**

Abonnementsavgift: Den avgiften Kunden betaler til Leverandøren for at et riktig antall samtidige Sluttbrukere kan bruke Febdok i den aktuelle lisensperioden.

Febdok: Febdok er en programvare utviklet for dokumentasjon og beregning av elektriske anlegg. Febdok er nærmere beskrevet på nettsidene under febdok.no og www.nhoelektro.no/febdok.

Febdok Nettsider: Leverandørens nettsider www.febdok.no inkludert www.nhoelektro.no/febdok og pålogging for Kunden på NHO Elektro Min Side.

Kunden: Med Kunden menes den juridiske enheten som kjøper lisens (dispensasjonsrett) til Febdok fra Leverandøren for Kundens Sluttbrukere i henhold til Lisens- og supportavtale for Febdok.

Leverandøren: NHO Elektro ved Installatørens Service og Opplysningskontor med org.nr. 971 033 517.

Sluttbruker: Med Sluttbruker menes den fysiske personen som logger seg inn i og bruker Febdok.
- Rettigheter**
 - Leverandørens rettigheter**

Leverandøren med eventuelle underleverandører har alle opphavsrettigheter eller andre immaterielle rettigheter til Febdok.
 - Sluttbrukers rettigheter**

Så lenge Kunden har betalt Abonnementsavgift for Febdok, har Sluttbrukeren en ikke-eksklusiv, ikke-overførbar og tidsbegrenset disposisjonsrett (bruksrett eller lisens) til Febdok i objektkode på den måten som spesifisert på Febdok Nettsider.

Sluttbruker har også rettigheter som rettmessig bruker av Febdok etter preceptorisk lov som åndsverkloven. Ingen øvrige

Figure 7 You must accept the End user agreement.



Figure 8 After the agreement has been accepted, you can use the program.